
User Guide

Gravity pro

ICEMOBILE

WWW.ICEMOBILE.NET

Contents

一 Basic Knowledge	2
1.1 Brief Introduction.....	2
1.2 General Considerations	3
1.3 Battery Precautions.....	3
1.4 Charge Mobile Phone.....	4
1.5 Charger Precautions.....	5
1.6 Cleaning and Maintenance.....	5
二 Introduction	6
2.1 Icons	6
2.2 Phone Layout.....	7
2.3 Boot Using.....	8
2.3.1 Insert and Remove SIM Card.....	8
2.3.2 Power On/Off.....	9
2.3.3 Unlock SIM Card.....	9
2.3.4 Unlock Screen.....	10
三 Basic Functions.....	10
3.1 Dial	11
3.2 Contacts.....	13
3.3 Messages	15
3.4 File Management.....	16
3.5 Camera	17
3.6 Images	18
3.7 Video Player.....	19
3.8 Music Player.....	20
3.9 FM Radio.....	21
3.10 Recorder	22
3.11 Clock	23
3.12 Calendar	23
3.13 Calculator	24
3.14 Notepad	25
3.15 Flashlight.....	26
3.16 E-mail	Error! Bookmark not defined.
3.17 Browser	26
3.18 Searching.....	27
3.19 Download	29
3.20 Map.....	31
3.20 Barometric Altimeter	31
3.22 Backlog.....	24

3.23 Compass.....	25
3.24 Play Shop.....	26
四 Settings	45
4.1 SIM Card Management.....	38
4.2 WIFI	38
4.3 Bluetooth.....	39
4.4 Mobile Network	40
4.5 Flight Mode	40
4.6 Scenes Mode	41
4.7 Display	41
4.8 Storage.....	41
4.9 Application.....	42
4.10 Security.....	42
4.11 Language and Input Methods.....	43
4.12 Backup and Reset.....	44
4.13 Date and Time	44
4.14 Schedule Power On/Off	44
4.15 Auxiliary Functions.....	44
4.16 Developers Options.....	45
4.17 About the Mobile Phone	45
四 Common Problems & Solutions.....	45

一 Basic Knowledge

1.1 Brief Introduction

Thank you for purchasing ICEMOBILE –gravity pro. This instruction manual special used to guide you to understand the functions and features.

In addition to common call functions and records, this phone also provides you a variety of useful features and services. It will bring you more convenience and pleasure for your work and life.

Some of the services and functions described in this manual depend on the network and reservation service. Therefore, the menu items in the phone may not be available, various menus and functions of the phone may have different shortcut number

Our company reserves the right to modify the contents of this manual without prior notice.

1.2 General Considerations

- Your phone can only use our designated batteries and chargers. Using other products may cause battery leakage, overheating, explosion and fire.
- Do not put the battery, mobile phone and charger in a microwave oven or high-pressure equipment, or may cause circuit damage and fire and other accidents.
- Keep the phone away from children's reach to avoid they lest it as a toy, causing personal injury.
- On airplanes, in hospitals and other places prohibit the use of mobile phones, please turn off the phone.
- Do not use the mobile phone near the weak signal or high-precision electronic equipments. Radio wave interference may cause incorrect operation of the electronic equipment and other problems.
- Do not disassemble or modify the phone, otherwise it will cause damage, leakage and circuit faults to the phone.
- Avoid mobile phone too close to magnetic objects such as magnetic cards, mobile phone radiation wave may clear floppy disk, saving card, credit card information stored on.

1.3 Battery Precautions

- The use of mobile phone battery life is limited. In frequent charging battery time gradually shortened. The multiple charging is invalid, the battery life has been, you should replace the specified type of new battery.

- Do not throw old batteries in the general household waste. There is a clear local regulations for battery disposal, please follow the instructions required to do.

- Do not throw the battery into fire, otherwise it will cause the battery to ignite and explode. Installing batteries, do not apply pressure to force, otherwise it will cause the battery to leak, overheat, explosion and fire.

- If the battery fluid into the eye may cause blindness, then do not rub your eyes, rinse with fresh water, and then immediately to the hospital.


- Do not disassemble or modify the battery, otherwise it will lead to battery leakage, overheating, explosion and fire.

- Do not use or leave the battery beside the fire or heater hot place, otherwise it will lead to battery leakage, overheating, explosion and fire

- Do not wet the battery, otherwise it will cause the battery to overheat, smoke and corrosion. Do not use or leave the battery in direct sunlight or near hot car, otherwise it will result in fluid leakage and overheating may degrade performance and shorten the service life.

- Do not more than 24 hour continue charge.

1.4 Charge Mobile Phone

- The joint is connected to the mobile phone charger, mobile phone battery indicator  on the screen will flash cycle; charging if it is turned off, charging indicator will appear on the screen of the screen, the battery charging. If the phone is still excessive use when battery is low, probably over a period of time after charging indicates a symbol will appear on the screen charge. When the on-screen battery indicator shows full, and no longer flashing, indicating that charging has been completed. After charging is complete, disconnect the AC power outlet which connect the phone and charger.

- If you do not have the charger with the power and the phone is disconnected, then after a fairly long period of time (about 5 to 8 hours), the battery consumption to a certain extent, the phone starts charging again. We recommend that you do not do

so, because it will your battery performance and life of some impact.

1.5 Charger Precautions

- Please use 220V AC. Using other voltage can cause leakage, fire or damage to the phone and charger. Prohibit short-circuit charger, otherwise it will cause electric shock, smoke and damage to the charger. Please do not use the charger in the case of the power cord damage, otherwise it will lead to a fire and electric shock.

- Please clean the dust on the power socket.

- Please do not put water container near the charger, to avoid overheating, leakage and malfunction caused by water spills. If the charger come into contact with water or other liquids, immediately unplug the power from the outlet down to prevent overheating, fire, electric shock and malfunction of the charger.

- Do not disassemble or modify the charger, otherwise it will lead to personal injury, electric shock, fire and damage to the charger.

- Please do not use the charger in the bathroom where high humidity, otherwise it will cause electric shock, fire and damage of the charger.











1.6 Cleaning and Maintenance

Mobile phone, battery and charger without waterproof performance, do not use in the bathroom where high humidity, also avoid being wet. With a soft, dry cloth to clean the phone, battery and charger. Do not use alcohol, thinner or benzene solution to wipe the phone.

二 Introduction

2.1 Icons

In the standby interface, may appear small ICONS, details are as follows

Icons	Instructions
	Time Display
	Alarm clock has been set and activated
	Show battery level
	Vertical bars indicate the signal strength of the GSM network signal.
	Indicates music playing
	Receives new message
	Missed Call
	Meeting Mode
	Flight Mode
	Mute Mode
	Activate USB
	Access Restricted

2.2 Phone Layout



Keys	Instructions
①Call Key	Press this key to enter the call record interface and dial out.
②End Key	Press this key to hang up in the call interface; Other interface, press the key to close screen, then bright screen.
③Menu Key	In any mode, press this key to display the current menu options.
④Return Key	Return to the previous menu.

⑤Home Key	Non the standby state, press this key can be directly back to the standby interface. Long press to open the recent task.
⑥Power Key	Long press this key to turn off/on. Short press this key to lock the phone. Light the screen.
⑦USB Jack	Headset and USB Jack
⑧Camera Key	Press this button to enter the camera viewfinder interface, then to take photos.
⑨SOS Key	Long press to dial emergency number and send a message for help.
⑩Volume Key	Ongoing call and audio play interface, press the two side keys to adjust the volume.
(11)Camera	Camera
(12) Flashlight	Camera flashlight, open the flashlight program can be used as a flashlight lighting.
(13) Loudspeaker	Loudspeaker

2.3 Boot Using


2.3.1 Insert and Remove SIM Card

Turn off the phone, remove battery and other external power supply. According to the mobile phone label inserted SIM card. When you need to take out the SIM card, please

turn it off, take out the battery, then remove SIM card from SIM card holder.


2.3.2 Power On/Off



- To turn on the phone, please long press the power key on the phone up side.
- Turn off the phone, long press the power key. The following message box pops up, select "Off".
- Press the power key to switch phone in addition, you can also choose to reboot the phone, select the flight mode, mute mode, vibration mode and standard mode.



2.3.3 Unlock SIM Card

In order to prevent illegal use, SIM card using PIN1 (Personal Identification Number) code encrypt protection. Elected to use the function, every time you must enter PIN1 code when the phone is switched on, so that you can unlock the SIM card, and then send or receive the call.



Press the ON / OFF key to boot the phone; enter PIN1 code, press  to clear the error input, press  to confirm

If you enter the wrong PIN1 code in several times, SIM card will be locked, then please contact your SIM card network operator.

2.3.4 Unlock Screen



In order to prevent unauthorized use, you can set your phone screen lock. Elected to use this function, every time you light up the screen, you must draw your unlock pattern, so that you can unlock the phone, and then send or receive calls


Users can clear the unlock pattern (see "Security Settings"), in this case, the phone can not prevent unauthorized use




≡ Basic Functions


3.1 Dial




In standby interface to click  into the dial-up interface, click the digital on the screen to dial the number. If you need to change the phone number, please click  back to delete characters, then dial the number. Press the Menu key to pop-up menu options, as shown, you can choose to send SMS, added to the "Contacts" or the Settings, etc.













You can also touch  at the top of screen, enter to the call records interface to dial out. Or click  at the top of the screen, enter the contact interface to dial out. Click  directly in the standby interface, can also into the contact interface to dial out.




After the call is connected as shown:





- ◆ Click  to open the dial pad, according to the call prompted to input the corresponding number, such as 10086 when playing prompts.
- ◆ Click  to open the speaker, amplified voice calls.
- ◆ Click  to mute, do not send local voice.
- ◆ Click  to keep current on the phone or restore is held.
- ◆ Click  to use the keyboard to enter a contact or from call logs, contacts, select the relevant contact, to make a new call.
- ◆ Click  to end the current call


Interface as shown when a call comes in, tap  and drag  to answer the phone, drag  to reject a call, drag  to send SMS.





3.2 Contacts.


You can directly open the "Contacts" on the main screen, or open it in "Dial" app. Enter the contact interface as shown, click on a contact to view the contact information stored,

click on  to call the contact, click on  to send SMS to the contact. Press the Menu key to modify, share and delete the contact







In the contact interface, click on  to quickly search contacts, click on  to add a new contact. You can choose to save the newly added contacts to the phone or the SIM card and save the contact name, phone, email, address and other information, as shown:


In the contact interface click menu button will pop up the following menu options, you can according to your need to delete, import, export and share contacts and other operations.




3.3 Messages

Click  on the home screen, enter the message interface. Click  to enter the written message interface. In the "input names and numbers" area, input the number, or click on the contact icon, select a number from your contacts. In the "input the text message" area to edit message content. Touch  to send a message after completion.




Click  on the screen, can insert images, video, audio and other files, SMS will be automatically converted into MMS.





3.4 File Management

You can view and management the files which be stored locally on the phone or SD card.



You can copy the files, paste, rename, delete, share and other operations.





Click , you can select one or more files or folders to share, copy, delete, cut, rename and other operations. You can also reordered folder by name, size or date.




3.5 Camera


On the main screen, tap  into the application, and then click  to enter the camera viewfinder screen.





Click  to enter the camera setting mode, you can according to your needs for camera exposure, effects, shooting and other settings. As shown:




Click  to take a picture, click  to convert video interface, as shown:









3.6 Images

Tap  on the main screen to enter the application, and then click , you can view all the pictures and video files that saved in the mobile phone and SD card, press menu key to browse images, delete and grouping operation, etc.






3.7 Video Player

On the main screen, tap  into the application, and then click  to enter the video list. Click on the menu key you can delete, sort, and other operations. Select a video to play, click  to play the video into a small window, support background play mode. Click  to full-screen playback. Click time progress bar to forward and reverse operation. Click  to send video to message, Bluetooth, E-mail to share.








3.8 Music Player





On the main screen, tap  into the application, and then click  to enter the music player.








At the top of the screen, the artist, album, songs and playlists four ICONS respectively all the audio files are classified in the mobile phone. You can choose your favorite arrangement to find the songs


that you want to listen. Choose to play a song:

-  indicates pause/play song.
-  indicates continue playing.
-  indicates switch to last song, long press to rewind.
-  indicates switch to next song, long press to forward.
-  indicates the progress of the song playback (time display), sliding around the scroll bar to jump to any position in the song.



-  indicates on/off the shuffle.
-  indicates on/off repeat all songs.
-  indicates repeat current song.
-  indicates back to song list.


3.9 FM Radio



On the main screen, tap  into the application, and then click  to enter the radio. Into the radio, you need to plug in the headset cable, you can search channel. If this function is not prompted to not insert the headset, please pay a little attention when you using. Click  to enter the channel list; clicking  Stop / Play Radio; clicking , you can search for it, FM recording and other operations, as shown:







3.10 Recorder

On the main screen, tap  into the application, and then click  to enter the radio. You can record audio files.









- Start recording: Tap 
- Play recording: Tap 

- End recording: Tap 
- Pause recording: Tap 
- List of recording: Tap 



Recorded audio files successfully saved automatically generated file list, click  to view the recording or playback recording, and automatically save to your phone.


3.11 Clock

On the main screen, tap  into the application, and then click  to enter the clock., You can see the setting date and time, week and alarm in the clock interface. Click  to view and set the alarm; click  to open the stopwatch function; click  to select night mode, set menu and set the alarm, etc.




3.12 Calendar

Tap  on the main screen to into the application, and then click  to access the calendar.





Into the calendar interface, slide up and down, you can view the previous month and next month's calendar, click the menu key to select the new activity, refresh, search, set, and other related operations. Settings can be set calendar view and reminder. Figure:




3.13 Calculator






On the main screen, tap  into the application, and then click  to access the calculator. Your phone provides you a calculator with the four basic functions, allowing


you to perform simple arithmetic. Press the "Clear" to clear the recent input or the result.





3.14 Notepad

On the main screen, tap  into the application, and then click  into Notepad.

Click on  to add a new Notepad. Click the "Unclassified" area to classify the new added Notepad, mainly divided into work items, personal matters, family matters and learning issues.





3.15 Flashlight


On the main screen, tap  into the application, and then click on  to enter the flashlight. Click the "off" to open flashlight, click "on" to close flashlight.



3.16 E-mail



On the main screen, tap  into the application, and then click  to enter the e-mail. You can send email messages to anyone with an email address.

Enter the program and set up my account, then you can click on your email account has been built into the account, to start, edit, create account, delete operations, can be sent or received email like computers. The program requires network support.




3.17 Browser







On the main screen, tap  into the application, and then click  to enter the browser. The support of the network (WI-FI or GPRS) into Web browser lets you surf the Web on your phone, and view Web pages, like in a computer. You can create a bookmark on your phone and sync bookmarks with your computer. Directly from the main screen to quickly access your favorite sites.


In the search box, enter the content you want to find, click the Search icon, enter the relevant pages:




Touch the screen, the screen display URL above, display the menu below:





Click  to go to the previous page; Click  to enter next page; Click  to view the pages you have open, you can slide up and down, and select a page to enter; clicking , you can view your bookmarks, history, and saved web page.





Click on the menu key on the main page, you can refresh, close, save to bookmark, share web pages, settings, etc.





3.18 Searching



On the main screen, tap  into the application, and then click  to enter the search interface:




Enter the content you want to search, click the Searching key, select the type of search you want, such as web pages, contacts, etc.:





Click , enter the search results:





Click on the menu key on the main page, you can refresh, close, save to bookmark, share web pages, settings, etc.




3.19 Download



On the main screen, tap  into the application, and then click  to enter the download interface. You can view the content which have been downloaded or being download. On download content interface, press the Menu key can be sorted by size or time of operation.


3.20 Map

On the main screen, tap  into the application, and then click  to enter the map interface. You can click on the Search icon key under the screen, enter the destination you're looking for, search, Or click the line icon under the screen, enter the start and the end to query bus transit.






3.21 Barometric Altimeter



On the main screen, tap  into the application, and then click  to enter the barometric altimeter. You can view the pressure, temperature (temperature inside the phone) and altitude of your location. Press the menu key appears "Calibration" and "About" menu. You can be calibrated according to the local barometric pressure, and view the software features.





3.22 Backlog


On the main screen, tap  into the application, and then click  to enter the backlog. In the backlog interface, you can view the to do items and completed items, or

click on  bottom of the screen to add items. Add a items interface, you can enter a title, description. You can also set the deadline for your needs.



3.23 Compass


On the main screen, tap  into the application, and then click  to enter the compass interface. The compass icon on middle of the screen will change the orientation of the phone, an icon appears above the corresponding angle, such as:






, as shown:




3.24 Play Service





On the main screen, tap  into the application, and then click  to enter the Play Store. Play store when you first enter, you need to create a new account, you can follow the prompts to complete the creation process. When you use the account to enter Play store home page, you can see a variety of mobile phone software, you can choose according to your needs and install it to your phone. You can slide the screen to the category, Top Free, Top Free new products, fastest rising to find the popular software.




In the Play Store screen, click an icon on your favorite software, enter the installation interface:




Click **INSTALL** to install the selected software, application permissions in the popup choose to accept, the phone automatically starts to download the software, if you want to cancel the download, click  next to the download progress bar.




After the download is complete, click Open, you can start to apply your newly downloaded this software:



In the Play Store homepage, click the menu key to bring up the following menu:





Select "My Application", you can view your "Installed application" and "All Applications", you can also reset accounts, notifications, auto-updating applications, password, etc.



Other Google services, such as: Gmail, Google set, Google Talk, will need to apply for Google account, after landing Google services in order to properly use Google related services.

四 Settings


On the main screen, tap  into the application, and then click  to enter the settings, you can according to your need to personalize your phone settings.


4. 1 SIM Management


Set the SIM card for voice calls, video calls, messages, data connections and other settings.


4. 2 WIFI


Click WIFI, enter WIFI interface, click "Open" icon on the top right of the screen, your phone will automatically search for wireless networks within range.



Click  to refresh the network list, if you get a license, you can click on your wireless network license has been made, enter the password in the input area, and then click "Connect", the connection is completed show "Connected", then your phone it can be connected.




You can also click  on the screen in the lower right corner, add a network:




4.3 Bluetooth

Activate Bluetooth, the phone automatically searches for Bluetooth devices seen around, you can click on any device with which to pair the device to pair, with the search after connection for file transfer and other operations.



4.4 Mobile Network

In this menu you can turn on or off the data connection, enabling 3G services, network operators and other options:






4.5 Flight Mode

When clicked, it will disable all wireless connections, calls and messages are not available

4.6 Scenes Mode

The following modes can be set up on the phone: Standard, Mute, Meeting, Outdoor;

You can also click  on the left corner to add a new mode, click  on the lower right corner to return to the default settings.




4.7 Display

Open to personalize set the phone brightness, scene, wallpaper, themes and automatically rotate the screen, etc.


4.8 Storage

You can view the phone and SD card total capacity, free space, you can choose the preferred installation location and format the phone memory.



4.9 Application


You can view the phone has downloaded applications, phone storage applications, running applications and all applications. You can click on the menu key to reorder these programs by size




4.10 Security



Set the screen security, SIM card lock, password, device management, credential storage

and other settings:



4.11 Language and Input Method

You can choose your preferred language and input method, you can also click  for the input method for the relevant settings:




4.12 Backup and Reset

You can backup my data, automatically restore, restore the factory settings and operations, restore factory settings will delete all personal data on your phone.

4.13 Date and Time

You can choose to automatically determine the date and time, and automatically determines the time zone, use the 24-hour format, and select the date format and other operations:




4.14 Schedule Power On/Off

Set the time to automatically turn on or off the phone.

4.15 Auxiliary Function

To set fast boot, auto-rotate screen, large font, press the "Power" key to end the call and other functions:



4.16 Developer Options

You can set desktop backup password, unlock the screen, the SD card read and write protection, USB debugging and other different applications.

4.17 About Phone

View phone's current signal, power, service status, the phone's software and hardware information.

五 Common Problems & Solutions

If an exception occurs while using your phone, please refer to the following table to troubleshoot

Common problems	The causes	The solutions
Poor signal	Using the mobile phone in poor	Try to avoid

reception area, such as nearby

	buildings or basement, the radio waves cannot effectively communicate;	
	Using the mobile phone in the call dense period, such as commute time, line congestion caused by the inability of the calls.	Try to avoid
	Associated with the launch of the base station network built near and far	Can ask Internet service providers provides service area map
Echo or noise	Due to poor network trunk, is a regional problem	Hang up and redial, trunk lines may replace good one.
	Some regional bad line	
Standby time shorter	Standby time is related to the network system setting	Turn off the mobile phone in the poor reception area.
	The battery need to replaced, please replace new battery.	Please replace new battery.
	The phone will continue to search base station, it will use a lot of battery power, causing the standby time become shorter.	Please move to strong signal place or turn off the phone.
Unable to boot	The battery power is exhausted.	Check the battery power or charge it.
SIM card error	SIM card is damaged	Contact your network service supplier.
	SIM card not installed	Make sure SIM Card has been

		installed.
	SIM card metal surface have dirt	Use clean cloth to brush the SIM card metal contact point
unable to connect the network	SIM card is invalid	Contact your network service supplier.
	Beyond the GSM or 3G network service area.	Ask your network service supplier the service area.
	The signal is weak	Please move to the strong signal place to retry
Calls unable to call	set up the call barring function	cancel the call barring function
	set up the fixed dial function	cancel the fixed dial function.
PIN error	input incorrect PIN Code in three times	contact your network service supplier.
Unable to charge	Battery or charger damaged	need to replace new battery or charger
	Charge in lower than -10℃ or higher than 55℃ environment	change the charging environment
	Bad contact	check whether the plug connection well
Unable to add phonebook record	Phonebook memory is full	delete some part of phonebook record.

unable to set up some function	Network provider does not support this feature, or you did not apply for this function	contact your network provider.
--------------------------------------	--	-----------------------------------